730 0218, 4

NADC

# NAVAL AIR DEVELOPMENT CENTER

WARMINSTER, PA. 18974

REPORT NO. NADC-73019-30

17 JAN 1973


LIQUID OXYGEN SAMPLER EVALUATION

PHASE REPORT

AIRTASK A510 5103/0014/3510000002 Work Unit A5311B-40

Approved for public release; distribution unlimited.

19970609 156



#### NOTICES

REPORT NUMBERING SYSTEM - The numbering of technical project reports issued by the Naval Air Development Center is arranged for specific identification purposes. Each number consists of the Center acronym, the calendar year in which the number was assigned, the sequence number of the report within the specific calendar year, and the official 2-digit correspondence code of the Command Office or Functional Department responsible for the report. For example: Report No. NADC-73015-40 indicates the fifteenth Center report for the year 1973, and prepared by the Crew Systems Department. The numerical codes are as follows:

CODE	OFFICE OR DEPARTMENT
00	Commander, Naval Air Development Center
01	Technical Director, Naval Air Development Center
02	Program and Fiscal Management Department
03	Anti-Submarine Warfare Program Office
04	Remote Sensors Program Office
05	Ship and Air Systems Integration Program Office
10	Naval Air Facility Warminster
20	Aero Electronic Technology Department
30	Air Vehicle Technology Department
40	Crew Systems Department
50	Systems Analysis and Engineering Department
81	Administration Department

PRODUCT ENDORSEMENT - The discussion or instructions concerning commercial products herein do not constitute an endorsement by the Government nor do they convey or imply the license or right to use such products.



#### DEPARTMENT OF THE NAVY

NAVAL AIR DEVELOPMENT CENTER WARMINSTER, PA. 18974

#### AIR VEHICLE TECHNOLOGY DEPARTMENT

REPORT NO. NADC-73019-30

17 JAN 1973

## LIQUID OXYGEN SAMPLER EVALUATION PHASE REPORT

AIRTASK A510 5103/0014/3510000002 Work Unit A5311B-40

A comparative analysis of the Navy's G-276 Liquid Oxygen Sampler and a modified sampler originally designed by the Naval Air Test Center, Patuxent River, Maryland was made. Evaluation of the samplers was made on the basis of efficiency, reliability, convenience, safety and cost.

Reported by:

D. P. HORNICK, Chemical Engineer

Materials Characterization Section

Reviewed by:

E. R. WRIGHT, Supervisor

Materials Characterization Section

Approved by:

G. K. HOLMES, Head

Materials Protection Branch

F. S. WILLIAMS, Superintendent Aero Materials Laboratory

Approved for public release; distribution unlimited.

#### INTRODUCTION

Effective quality control over liquid oxygen supplies from manufacturer to final storage facility requires efficient sampling procedures and accurate analysis. Samples must be obtained which are free from external contamination and must be transported to test facilities in leak-proof containers. Deficiencies in the Navy sampling equipment has promoted work on a new type of sampling system initiated by the Naval Air Test Center, Patuxent River, Maryland. Modifications of this unit have been made by the Naval Air Development Center and a comparative study was made of the two techniques with respect to sampler efficiency, convenience, reliability, cost and safety.

#### DESCRIPTION

The sampler presented in this report is a modification of a sampler designed by the Naval Air Test Center, Patuxent River, Maryland. The original design of this sampler is shown in Fig. 1.

The description and component parts of the G276 sampler (Figures 2 and 3) can be found in Report No. NADC-MA-6976. The description, operation and component parts of the modified Patuxent River sampler are contained in the following pages.

This modified unit consists of two sections (Fig. 4): the actual sampling unit and a collecting cylinder (FSNRM8120-255-2799) which is the same cylinder used in the G276 sampling system. The actual sampling unit (Fig. 5) is comprised of: an inlet to the manifold with a ball valve to control the flow of LOX (liquid oxygen) to the sampler; a small cylinder (bailout bottle) where the sample of LOX is stored during the sampling time; an overflow line with ball valve which permits the LOX to escape when the small cylinder is full; a pressure relief valve which makes the unit safe from over-pressurization during sampling; a pressure gauge to indicate the amount of sample collected; and an outlet with a ball valve to permit the gaseous oxygen to flow into the large sample cylinder.

#### **OPERATION**

The actual operation of this unit is relatively simple. The unit is attached to the liquid oxygen source by the use of stainless steel flexible tubing while the sample cylinder is attached to the other end of the unit (Fig. 4, 6 and 7). When this hook-up is complete, valves 1, 2 and 3 (Fig. 5) and the sample cylinder containing residual oxygen from previous tests are opened and this residual oxygen is allowed to flush out the entire system. When this step has been completed, valve 3 is closed and liquid oxygen from the source is allowed to flow into the sampling unit. This flow is continued until the small steel cylinder is full as indicated by a steady stream of LOX flowing from the overflow outlet. When such a state has been attained,

valves 1 and 2 are closed while at the same time the LOX source is shut-off. Valve 3 is then opened which permits the gaseous oxygen to flow into the sample cylinder during the LOX warm-up period. This warm-up period is completed when no more pressure increase is observed. When this state is reached the sample cylinder is closed and the sample unit is disconnected from both the LOX source and sample cylinder. Due to the fact that this sampling unit can be disconnected from the sample cylinder, only one sampling unit is needed per LOX installation. Moreover, only the cylinder has to be shipped to the place of analysis.

#### DISCUSSION AND EVALUATION

Samples of oxygen using both the G276 and this new sampler were taken. Analysis was then made with respect to contamination using infrared spectrophotometry to compare the two methods of sampling. These data are presented in Table I as well as the IR spectrums in Figures 8 through 12. They show that this new method of sampling eliminates some contamination that is obtained using the G276 sampler. The methane (CH<sub>4</sub>), carbon dioxide (CO<sub>2</sub>) and water vapor (H<sub>2</sub>O) were almost always lower in concentration using this new sampling unit. The reason for this is basically two-fold. First, the G276 sampler is an open system while the new sampler is a closed system. An open system allows contamination from the atmosphere, while a closed system does not. Secondly, with the G276 sampler the contaminants are concentrated due to some initial boil-off of the LOX.

While it can be seen from the infrared spectra, (Figures 8 through 12) and the data presented in Table I, that the difference in contaminant concentration between the samples of LOX using the two samplers was significant, it could not be considered extreme. This relatively narrow spread between the LOX samples is attributed to the fact that the sampling operation was performed by experienced personnel who were able to permit minimum exposure to the atmosphere and boil-off time.

One benefit of this new sampler is the cost. As stated previously only one unit is needed per LOX facility. The unit has a cost of approximately \$120. Furthermore, the oxygen sample cylinder would represent no additional cost because the Navy is presently using this for the G276 sampler.

The only problem encountered with this new sampling unit is that it is time consuming. The cool-down and warm-up times shown in Table I are quite long due to the mass of the unit. However, when time is not critical, this unit offers definite advantages.

#### **CONCLUSIONS**

It is concluded that the modified Naval Air Test Center sampling unit can be used to obtain better results from routine sampling of LOX supplies from storage facilities, cart, and truck deliveries than those obtained with the G276.

#### FUTURE PLANS

It is planned that further work be done on this sampler in the following, areas:

- 1. More extensive tests should be performed on oxygen supplies whose quality is questionable.
- 2. Further design work should also be initiated to eliminate the long cool-down and warm-up times.

## RESULTS OF ANALYSIS

PPM of CH, Present	23	25	27	20	29	29	20.5	28	36	26
PPM of CO Present	1.1	1.1	1.7	1,3	2.0		1.5	1.2	1.5	1.1
Total Pressure of sample Achieved (psig)	190	007	260	550	120	400	245	450	306	125
System Warm-up Time	:	17 min.	-	24 min.	ł	22 min.	,# *	18 min.	\$ \$ \$	26 min.
System Cool-down Time Min./Sec.	3/50	6/15	3/30	4/15	3/48	6 min.	1/30	4 min.	3/50	5/50
Temperature when sample was taken	80	80	81	81	69	69	84	84	69	69
Relative Humidity when sample was taken	71	71	72	72	78	78	20	20	78	78
Type of Sampling System	G276	NADC modified sampler	G276	NADC	6-276	NADC	G-276	NADC	G-276	NADC
Figure	<b>∞</b>	ω	6	6		10	11	<b>₽</b>	12	12





Figure 1. SCHEMATIC SHOWING DETAILS OF FABRICATION OF PAX AM SAMPLER







Figure 3. G276 SAMPLER - SAMPLING STAGE

Figure 4. ASSEMBLY OF THE MODIFIED SAMPLING SYSTEM

LOX SUPPLY



11

MODIFIED PATUXENT RIVER SAMPLER Figure 5.









Figure 7. MODIFIED PATUXENT RIVER SAMPLER - SAMPLING STAGE




foure 8.



igure 9.



igure 10.



fourte 11




Figure 12.

### UNCLASSIFIED Security Classification

Security classification of title, body of abstract and index ORIGINATING ACTIVITY (Corporate author)							
NAVAL AIR DEVELOPMENT CENTER		UNCLASSIFIED					
Air Vehicle Technology Department	2b. GROUP						
Warminster, Pennsylvania 18974							
REPORT TITLE							
LIQUID OXYGEN SAMPLER EVALUATION							
PHASE REPORT							
AUTHOR(S) (First name, middle initial, last name)							
D. HORNICK		•					
REPORT DATE	78. TOTAL NO. OF PAGES	7b. NO. OF REFS					
17 JAN 1973	. 20	0					
A. CONTRACT OR GRANT NO.	98. ORIGINATOR'S REPORT N						
b. PROJECT NO.	NADC-73019-3	30					
AIRTASK A510 5103/0014/3510000002							
Work Unit A5311B-40	9b. OTHER REPORT NO(5) (Any other numbers that may be assigned this report)						
d.							
0. DISTRIBUTION STATEMENT							
or oral modified oral care in .							
Approved for public release; distrib	ution unlimited.						
1. SUPPLEMENTARY NOTES							
1. SUPPLEMENTARY NOTES	12. SPONSORING MILITARY A	CTIVITY					
	Naval Air S	Systems Command					
	Washington,						
		, = • = • = = = -					

A comparative analysis of the Navy's G-276 Liquid Oxygen Sampler and a modified sampler originally designed by the Naval Air Test Center, Patuxent River, Maryland was made. Evaluation of the samplers was made on the basis of efficiency, reliability, convenience, safety and cost.

(PAGE 1)

UNCLASSIFIED Security Classification LINK A LINK B KEY WORDS ROLE ROLE ROLE WΤ Infrared spectrophotometric analysis Cryogenic materials Liquid oxygen

DD FORM 1473 (BACK)

#### DISTRIBUTION LIST

#### AIRTASK A510 5103/0014/3510000002 Work Unit A5311B-40

		No. of Copies	X.
NAVAIR (AIR 604)		. 16	
(2 for retention)			~
(1 for AIR 5203)			
(1 for AIR 52033)			
(1 for AIR 531A)			
(1 for AIR 5311B)			
(1 for AIR 3021)			
(1 for AIR 53301)			
(1 for AIR 532D)			•.
(1 for AIR 520C)			
(1 for AIR 52033C)			
(1 for AIR 52033B)		•	
(1 for AIR 52033A)			
(1 for AIR 4117B)			
(1 for AIR 411B)			
(1 for AIR 320A)			
NAFI, Indiana		. 1	
•		•	
WPAFB, Ohio (R&T Div., MAAS)	• • • • •	. 2	
NAVAIREWORKFAC, NAS, Quonset Point		. 1	
NAS, Pensacola		. 1	
NAS, Norfolk		. 1	
NAS, Alameda			
NAS, North Island			
NAS, Jacksonville			
MCAS, Cherry Point		. 1	
NAVAIRDEVCEN		. 29	
1 for 03 3 for 813			
1 for 20 1 for 303			
1 for 40 1 for 302			
1 for 50 3 for 30023		• •	
1 for 50-4 15 for 3022			
1 for 50.6			
NA (46)			
		AND CO.	
			10
		The second second	